# SiteManager Training Manual




Module A Chapter 2

Contract Administration (+)
Contract Records (+)
Projects

Section A-2-3 **Viewing Projects** 


**Student's Version** 

Indiana Department of Transportation August, 2007 Version 3.7b




## **Projects**


The Projects Window contains descriptions of the Contract's Projects. Every Contract must have at least one Project.




"Double-click" on Contract Administration (+) located on the Main Panel.



"Double-click" on Contract Records (+).



<sup>&</sup>quot;Double-click" on **Projects** icon.




The **Select Contract Project** panel will open:

If the **Select Contract Project** panel does not open then "click" on the **Open** button on the toolbar.


The bottom panel contains columns for:

- Contract ID: this is the identification number assigned to the contract.
- **Vendor ID:** this is the INDOT assigned number identifying the Prime Contractor.
- Fed State Proj Nbr: this is the assigned Federal or State Project Number.
- **Status:** this field indicates the current status of the contract, i.e. Pending, Active, Complete, Archived.
- **County:** this field contains a letter and number code identifying the county where the majority of the work is located.
- Lvl 2: this column indicates the District office administering the contract.
- Lvl 3: this column is not utilized by INDOT.
- Lvl 4: this column is not utilized by INDOT.
- Location Description 1: this column is the description of the physical limits of the contract.

Use the Scroll or Find, Filter, Sort technique to locate the appropriate contract. "Double-click" on the **Contract ID**.



Use the Scroll or Find, Filter, Sort technique to locate the appropriate project. "Double-click" on the project **PCN**.



There are three tabs located in the Projects window. They are as follows:


**Description:** The **Description** tab displays the Project description.

**Counties:** The **Counties** tab displays a list of Indiana counties and a list of those counties associated with the selected Project.

**Adjustment Indices:** The Adjustment Indices folder tab displays a list of available price adjustment indices and a list of those associated with the selected Project.

## **Description Tab**

**Description** Tab: The **Description** tab contains information describing the Project.



Contract ID: Contract ID is a unique identifier and is automatically populated.

**Project Nbr: Project Number** is a unique identifier and is automatically populated.

Fed St Prj Nbr: Federal/State Project Number is a unique identifier and is automatically populated.

Alt Prj ID: Not utilized

**Description:** The first Description field is information describing the Project, and is automatically populated.


**Description:** The second **Description** field is for additional information describing the Project, and is automatically populated.

**Spec Yr:** the **Specification Year** indicates the specifications used for contract items and materials and is automatically populated

**Unit Sys:** The **Unit System** is the type of measurement System used to calculate quantities. The choices will be either English or metric. This is automatically populated.

**Status: Status** indicates the current status of a Project

Acceptance	District Office Review	Under Litigation
Active Construction	Finalized	
Claim	Preliminary Estimate	
Completed	Spaces	



**Complete:** Complete check box indicates whether the Project work is complete.

**Auth Pay Limit: Authorized Pay Limit** is used to determine if a voucher will be processed. If the total payments exceed this amount, the voucher will not be processed. Leaving this field blank indicates that no cap exists for total payments...

**Release Retainage:** When the **Release Retainage** check box is check Retainage is automatically release when the Project is placed in completed status

**Acct Prj Nbr:** Is an accounting department-defined Project number. Currently not utilized by INDOT.


**Prj Type: Project Type** field identifies the type of construction that defines the Project and is automatically populated.

Work Type: Work Type identifies the major type of work being done in the Project and is automatically populated.

**Surface Type: Surface Type** field is the type of surface used in the Project and is automatically populated.

**Route Nbr:** Route number is the name of the route that the work is preformed at and is automatically populated.

**Section Nbr: Section Number,** 



**Road System:** identifies which system of Roadways the Project falls under, selected from the pull down menu;

City

County

**DNR** Road

Federal System

Frontage

**Institution Road** 

Interstate

National Highway System

Spaces

Special

State Road

Toll Road

**US** Highway

Road Name: Road Name is the text identifier of the project Roadway.


**Location:** Location is the description of where the project physically exist.

Engr Pct: Engineering Percentage is the Engineering construction percentage that represents the state cost (overhead) of managing a project.

**Location:** Location contains the reference post location.

Work Site: Work Site the federal designation for the type of route.

Beg Sta: Beginning Station Number the starting location for the project.



**Beg Termini: Beginning Termini** is the beginning Reference Post (RP) number for the project.

Latitude: Latitude Geographic coordinate of the worksite


End Sta: End Station Number the ending location for the project.

**End Termini**: **End Termini** is the ending Reference Post (RP) number for the project.

Longitude: Longitude Geographic coordinate of the worksite

#### **Generic Fields**

Any customization INDOT requires will be kept in a generic field.



"Click" on Services located on the tool bar and select Generic Fields.

Apprintion: IMTEDEECTION IMPORTMENT						
Object:	650	Generic String 1:	Generic Date 1:	00/00/00		
Location:	500	Generic String 2:	Generic Date 2:	00/00/00		
Cost Acct:	703	Generic String 3:	Generic Date 3:	00/00/00		
Fund:	400	Generic String 4:	Generic Date 4:	00/00/00		
Function:	94	Generic String 5:	Generic Date 53:	00/00/00		
PO Date:	03/28/05	Generic Code 1:	Generic Date 5:	00/00/00		
Approp:	850	Generic Code 2:	Generic Date 52:	00/00/00		
Generic String 52:		Generic Indicator 1:	Generic Date 54:	00/00/00		
Generic Number 1:	0	Generic Indicator 2:	Generic Date 55:	00/00/00		
Generic Number 2:	0	Generic Indicator 3:				
Generic Number 3:	0	Generic Indicator 4:				
		Generic Indicator 5:				

Object: Object is defaulted to OBJ

**Location:** Location is defaulted to 500

Cost Acct: is defaulted to 703

Fund: Fund is defaulted to 400


Function: Function is last 2 numbers of ORGN

**P. O. Date**: **P. O. Date** is the Date the purchase order is issued.

**Approp: Approp** is first 3 numbers of APPR UNIT


### **Counties Tab**

**Counties** Tab: The **Counties** tab displays a list of Indiana counties and a list of those counties associated with the selected Project.



# **Adjustment Indices Tab**

Adjustment Indices: The Adjustment Indices tab is not utilized by INDOT.



### **Viewing Projects**

#### **A-2-3 Group Exercise**

View the Project information on an active contract.

Log into SiteManager as: inquire

Password: pass

"Double-Click" on **Contract Administation** (+)

"Double-Click" on Contract Records (+)

"Double-Click" on **Projects** 

"Double-Click" on Contract R-90002

"Double-Click" on PCN 9620710

View information on **Description Tab** 

View information on Counties Tab

"Click" on the Close button located on the toolbar to exit.